

# Quick Setup Guide **Omni**


AT-3LE | AT-5LE | AT-3T-LE | AT-5T-LE




## Installation

### Install at least 12 inches from Camera

For optimal performance each illuminator should be at least 12 inches away from any ceiling mounted camera to prevent light from going directly into camera.




1. Using a hole saw make a 2 1/4" installation hole.
2. Install metal clips (provided) onto opposite sides of the hole.



3. Remove at least 3" of insulation around the light to allow proper cooling. *If necessary use a recessed light draft stop cover.*

4. Plug in power cord or PoE cable illuminator should turn ON.



## POWER

**12 VDC**

OR

**PoE or PoE+**

Applying voltage other than the required range may cause permanent damage and VOID WARRANTY.




**WARNING!** Infrared light is not visible. Do not view directly with optical instruments (magnifiers) or stare directly into the illuminator at close distance.

*Do not attempt to open or modify the light as this will void the warranty. If you need a modification, electric or physical, contact us directly. We will let you know if it can be done. All changes MUST be made at our factory.*



**Ceiling height affects illumination coverage, higher ceilings allow for wider coverage.**



Example AT-5LE:

9ft Ceiling  
40ft x 40ft

12ft Ceiling  
60ft x 60ft

20ft Ceiling  
100ft x 100ft



QUESTIONS ? **(801) 519-0500** or [support@axtontech.com](mailto:support@axtontech.com) | [axtontech.com](http://axtontech.com)



801 Robinson Drive, Suite #500, North Salt Lake, UT 84054  
☎ 801/519-0500 🏠 801/519-0501 ✉ sales@axtontech.com

